



**WORLD'S BEST  
ALLOY BULLBARS**

[ecb.com.au](http://ecb.com.au)

**A:** 29 Snook St Clontarf QLD 4019

**P:** PO Box 122 Margate QLD 4019

**T:** 07 3897 5700

**E:** [info@ecb.com.au](mailto:info@ecb.com.au)

**ABN:** 25 010 676 034

Part of GUD Holding Limited - ASX: GUD



[customalloy.com.au](http://customalloy.com.au)

## **B3IS0314SY**

### **FITTING INSTRUCTIONS**

#### **ISUZU NPS NH 4X4 08- VICTORIA SES SPEC DELUXE 3 BULLBAR TO SUIT 12000/15000LB WARN WINCHES VEHICLE FRONTAL PROTECTION SYSTEM (VFPS) FOR AIR BAG & ADR COMPLIANT VEHICLES**

Check installation hardware before commencing.

1. Park vehicle on level ground. Remove steel mounting brackets and hardware from bullbar.
2. Remove front bumper, four (4) bolts. Remove tow hook and discard bolts.
3. Remove 8mm bolts holding earth strap to chassis rail on driver's side.
4. Fit steel mounting bracket using four (4) M10 x 1.25 x 30mm bolts and heavy-duty flat washers to front face of chassis rail. Leave bolts loose until final adjustment.
5. On driver's side attach steel mounting bracket using one (1) M8 x 40mm bolt and washer, with ½ x 1 ½ bolt, flat washers and nyloc nut. Re attach earth strap to outside of steel mounting plate.
6. On Passenger side attach steel mount bracket using M14 x 1.5 x 50mm bolt, spring and flat washers to rear hole captive nut, with ½ x 1 ½ bolt, flat washers and nyloc nut in front hole.
7. Attach steel support brackets using two (2) ½ x 2 bolts nyloc nuts and washer and two (2) ½ x 6 ½ bolts, nyloc nuts and washer (per side).
8. Disconnect wiring harness from park lamp. Plug supplied harness to park lamp bulb holder. Refit original harness to supplied harness.
9. Attach bullbar to steel mounting brackets using two (2) eye bolts and washers (supplied) and leave loose.
10. Insert two (2) 9/16 x 2 bolts, nyloc nuts and four washers to bullbar pivot points at rear of bottom skirting. Tighten nyloc nuts enough to engage the nyloc and still allow bullbar to pivot on the bolts. Tighten eye bolts.
11. Align bullbar to vehicle and tighten bolts on side of chassis rail. Once bullbar is aligned, tighten four (4) M10 x 30mm bolts on front of chassis.
12. On drivers side drill 13mm hole above ½" bolt. Blow filings clear and treat all exposed metal with a rust inhibitor. Insert ½ x 1 ½ bolt, washers and nyloc nut and tighten.
13. Connect parker harness to lights. Check operation of lights and tilting of bullbar.
14. Place tilt bullbar warning sticker (supplied) to rear of cabin near tilt lever.



**WORLD'S BEST  
ALLOY BULLBARS**

[ecb.com.au](http://ecb.com.au)

**A:** 29 Snook St Clontarf QLD 4019

**P:** PO Box 122 Margate QLD 4019

**T:** 07 3897 5700

**E:** [info@ecb.com.au](mailto:info@ecb.com.au)

**ABN:** 25 010 676 034

Part of GUD Holding Limited - ASX: GUD



[customalloy.com.au](http://customalloy.com.au)

### Fitting Kit

4	-	M10 x 1.25 x 30mm Bolts
4	-	10mm Heavy duty flat washers
1	-	M14 x 1.5 x 50mm Bolt
1	-	14mm Flat washer
1	-	14mm Spring washer
1	-	M8 x 1.25 x 40mm Bolt
1	-	8mm Spring washer
1	-	8mm Flat washer
3	-	½ x 1 ½ Bolts
4	-	½ x 2 Bolts (For winch mounting bracket)
4	-	½ x 6 ½ Bolts (For winch mounting bracket)
11	-	½ Nyloc nuts
22	-	½ Flat washers
1	-	3/8 x 1 ½ bolt
1	-	3/8 Nyloc
1	-	3/8 Flat washers
2	-	Isuzu parker only harness
1	-	Tilt cab sticker

### Attached to Bullbar

2	-	¾" Eye bolts
2	-	¾" Flat washers
2	-	9/16 x 2 ½" Bolts
2	-	9/16 Nyloc nuts
4	-	9/16 Flat washers



**WORLD'S BEST  
ALLOY BULLBARS**

ecb.com.au

A: 29 Snook St Clontarf QLD 4019

P: PO Box 122 Margate QLD 4019

T: 07 3897 5700

E: info@ecb.com.au

ABN: 25 010 676 034

Part of GUD Holding Limited - ASX: GUD



customalloy.com.au


# DESPATCH CHECKLIST

## B3IS0314SY

### ISUZU NPS NH 4X4 08- VICTORIA SES SPEC DELUXE 3 BULLBAR

Work Order #	
Finish:	
Transport:	
Due Date:	

OC	_____	1	Steel Winch Mounting Bracket
OC	_____	1	Pair Steel Support Brackets
OC	_____	2	3" Overrides (CA01 Plastic)
OC	_____	2	Custom Alloy Badges – <b>Fitted to Overrides</b>
OC	_____	2	LED Parker Lights (ICLED33INDPRK-95202CUST)
WR	_____	1	Steel Winch Mounting Bracket – <b>Fitted to Bar</b>
WR	_____	1	Pair Steel Support Brackets – <b>Fitted to Bar</b>
WR	_____	2	3" Overrides (CA01 Plastic with CA badges) – <b>Fitted to Bar</b>
WR	_____	2	Eyebolts ( $\frac{3}{4}$ " UNC ZP) and Washers – <b>Fitted to Bar</b>
WR	_____	2	2 $\frac{1}{2}$ " x $\frac{9}{16}$ " UNC Bolt Grade 8H/T – <b>Fitted to Bar</b>
WR	_____	2	$\frac{9}{16}$ " Nyloc Nut – <b>Fitted to Bar</b>
WR	_____	4	$\frac{9}{16}$ " Flat Washer – <b>Fitted to Bar</b>
WR	_____	2	LED Parker Lights (ICLED33INDPRK-95202CUST) – <b>Fitted to Bar</b>
WR	_____	1	Bolt Kit – <b>Taped to Mount</b>



Is this product "the best it can be" Yes

If **NO** fix before continuing

All parts checked and completed by:

Nut and bolts: \_\_\_\_\_ Date \_\_/\_\_/\_\_

Order control: \_\_\_\_\_ Date \_\_/\_\_/\_\_

Final wrap check: \_\_\_\_\_ Date \_\_/\_\_/\_\_



**WORLD'S BEST  
ALLOY BULLBARS**

[ecb.com.au](http://ecb.com.au)

**A:** 29 Snook St Clontarf QLD 4019

**P:** PO Box 122 Margate QLD 4019

**T:** 07 3897 5700

**E:** [info@ecb.com.au](mailto:info@ecb.com.au)

**ABN:** 25 010 676 034

Part of GUD Holding Limited - ASX: GUD



[customalloy.com.au](http://customalloy.com.au)

