



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

NB7T96SY

REPLACES: 01.05.07
REVISED: 11.07.10

FITTING INSTRUCTIONS

TOYOTA 79 SERIES LANDCRUISER 3/07on 76mm SERIES 2 NUDGE BAR VEHICLE FRONTAL PROTECTION SYSTEM (VFPS) FOR AIR BAG & ADR COMPLIANT VEHICLES

Check installation hardware before commencing.

1. Remove front under body plastic plate from underside of radiator. Four 14mm bolts. Retain for re-fitment.
2. Remove tow hooks. Three 17mm head bolts (per side).
3. Using one M10 x 1.25 x 30mm bolts, flat and spring washers (per side) (supplied) fit top steel mounting bracket (supplied) to hole above top hole in tow hook. **FINGER TIGHTEN ONLY.**
4. Re-fit tow hook using original bolts with lower steel mounting bracket (supplied) between vehicle and tow hook. **See figure 1.**
5. Align top mounts evenly through bar and **TIGHTEN** top bolt and front top bolt of tow hook. **See figure 2.**
6. Push lower steel mounting bracket as high as possible on chassis and **TIGHTEN ALL BOLTS.**
7. Refit front under body cover using original bolts.
8. Fit protection bar to mounts using four ½ x 1 ½ bolts, nuts, flat and spring washers (supplied) on lower holes (nuts to outside) and two 3/8 x 1 ¼ bolts, nuts, flat and spring washers (supplied) for top holes (nuts to outside). **DO NOT TIGHTEN.**
9. Align protection bar with vehicle. **See figure 3** for front view **and figure 4** for side view. **TIGHTEN ALL BOLTS.**

ENSURE NUMBER PLATE IS CLEARLY VISABLE

Note: When fitting/refitting the licence plate to the vehicle, ensure there is no obstruction to licence plate vision in accordance with local authorities. If required relocate licence plate to an alternate location.

Further VFPS Notes:

- a) Do not attach VFPS to the vehicle using anchorages not intended for this purpose (e.g. engine mounting bolts).
- b) Do not use this product for any vehicle make or model, other than those specified by the VFPS manufacturer.
- c) Do not remove the plaque or label from the VFPS.
- d) Do not modify the structure of the VFPS in any way.
- e) No accessory or fitment should project forward of the VFPS forward profile.
- f) **ENSURE THESE INSTRUCTIONS ARE LEFT WITH VEHICLE OWNER AND/OR OPERATOR.**

IMPORTANT INFORMATION

Periodically check bolts and nuts for correct tightness, especially if travelling on rough roads



East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

WORLD'S BEST
ALLOY BULLBARS

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

FITTING KIT

2 – 6mm lower steel mounting brackets.	4 – 10mm spring washers.
2 – 6mm upper steel mounting brackets.	4 – ½ x 1 ½ bolts / nuts.
2 – M10 x 1.25 x 30 bolts.	8 – ½ flat washers.
2 – 3/8 x 1 ¼ bolts / nuts.	4 – ½ spring washers.
6 – 10mm flat washers.	



Figure 1 – Passenger side shown (bumper removed for photo)




Figure 2 - Passenger side shown (bumper removed for photo)



Figure 3 – Front view shown




Figure 4 – Side view shown



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

We value your comments

Dear Fitter,

ECB would like to know how you went with the installation of this product. We value your comment and may need to contact you to clarify some details so please complete your contact details clearly.

We would appreciate if you could complete as many of the following details as possible.

Your Name:	Your contact No.
Product Part No.	Product Invoice No.
Product Description:	Make, model, and year of vehicle:
Product Work Order No.	Company your from/Company product purchased from:

Date of Fitment: ____/____/____

Was the fitting hardware supplied complete?

Yes

No

If no what was not supplied

Did the installation go well?

Yes

No

Please provide comments

Please draw diagrams if you need to.

Post to
Reply Paid 122
PO Box 122
Margate QLD 4019

Fax to
(07) 3283 1168



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia



WORLD'S BEST
ALLOY BULLBARS

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

DESPATCH CHECKLIST NB7T96SY

Work Order #	
Finish:	
Transport:	
Due Date:	

- 2 – 6mm lower steel mounting brackets
- 2 – 6mm upper steel mounting brackets
- 1 – Bolt Kit



Is this product “the best it can be” Yes _____ / _____
Wrapper’s initials / Checker initials

If **NO** fix before continuing

All parts checked and completed by:

Nut and bolts: _____ Date __/__/__

Order control: _____ Date __/__/__

Final wrap check: _____ Date __/__/__



East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

WORLD'S BEST
ALLOY BULLBARS

