

Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

> REPLACES: 08.08.08 REVISED: 28.06.10

NBHU70SY

FITTING INSTRUCTIONS

HYUNDAI ILOAD AND IMAX 02/08on VEHICLE FRONTAL PROTECTION SYSTEM (VFPS) FOR AIR BAG & ADR COMPLIANT VEHICLES

Check installation hardware before commencing.

- 1. Remove under body guard, eight 10mm head bolts. See figure 1.
- 2. Remove two plastic screw clips (per side) from front of inner guard and pull rearward away from bumper.
- 3. Using 10mm drill, enlarge four holes where under body guard was removed. See figure 2. NOTE: Blow swarf clear and treat drilled holes with a rust inhibitor.
- 4. Place 3/8 x 2 bolts and washer on wire (supplied) through holes in chassis rails. Fit ECB steel mounting brackets to bolts and attach with flat washers, spring washers and nuts (supplied). **See figure 3. FINGER TIGHTEN ONLY.**
- 5. To fit ECB Nudge Bar, lay Nudge Bar on soft cloth in from of vehicle with mount side of Nudge Bar under front of vehicle to outside of steel mounting brackets. **See figure 4.** Attach rear of Nudge Bar to steel mounting brackets using 3/8 x 1 ½ bolt, flat washers, spring washers and nuts (supplied). Swing Nudge Bar into position and install front 3/8 x 1 ½ bolts, flat washers, spring washers and nuts (supplied). **See figure 5. FINGER TIGHTEN ONLY.**
- 6. Align ECB nudge bar with vehicle and tighten ECB steel mounting brackets to vehicle. See figures 6 and 7.
- 7. Check alignment and tighten steel mounting brackets to Nudge Bar.
- 8. Tighten all bolts.
- 9. Refit inner guards to sit over top of Nudge Bar tube.
- 10. Enlarge holes in plastic under body guard to fit over 3/8 bolts previously installed. **See figure 8.** Refit to vehicle using flat washers and 3/8 nyloc nuts (supplied) and original bolts in other holes. **Caution: Do not over tighten as plastic will split.**

ENSURE NUMBER PLATE IS CLEARLY VISABLE

Note: When fitting/refitting the licence plate to the vehicle, ensure there is no obstruction to licence plate vision in accordance with local authorities. If required relocate licence plate to an alternate location.

Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

Further VFPS Notes:

- a) Do not attach VFPS to the vehicle using anchorages not intended for this purpose (e.g. engine mounting bolts).
- b) Do not use this product for any vehicle make or model, other than those specified by the VFPS manufacturer.
- c) Do not remove the plaque or label from the VFPS.
- d) Do not modify the structure of the VFPS in any way.
- e) No accessory or fitment should project forward of the VFPS forward profile.
- f) ENSURE THESE INSTRUCTIONS ARE LEFT WITH VEHICLE OWNER AND/OR OPERATOR.

IMPORTANT INFORMATION

Periodically check bolts and nuts for correct tightness, especially if travelling on rough roads

FITTING KIT

2 – ECB steel mounting brackets	8 – 3/8 spring washers
$4 - 3/8 \times 2$ bolt and washer on 300mm wire	8 – 3/8 nuts
4 – 3/8 x 1 ½ bolts	2 – 3/8 Nyloc nuts
10 - 3/8 flat washers	



Figure 1: Front under body guard showing front four 10mm head bolts.



Figure 2: Enlarge holes to allow 3/8 bolts on wire for steel mount fitment.

Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019

Australia



Figure 3: Fitting ECB Steel mounts to 3/8 x 2 bolts and washers on wire in chassis



Figure 4: Nudge Bar laid out ready for fitment.



Figure 5: Rear bolts installed before Nudge Bar swung up onto vehicle.



Figure 6: Nudge Bar front view



Figure 7: Nudge Bar side view



Figure 8: Drilled plastic cover fitted back to vehicle using 3/8 nyloc nuts and flat washers



Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

We value your comments

Dear Fitter,

ECB would like to know how you went with the installation of this product. We value your comment and may need to contact you to clarify some details so please complete your contact details clearly.

We would appreciate if you could complete as many of the following details as possible.

Your Name:	Your contact No.	Your contact No.	
Product Part No.	Product Invoice No.	Product Invoice No. Make, model, and year of vehicle:	
Product Description:	Make, model, and ye		
Product Work Order No.	Company your from	/Company product purchased from:	
Date of Fitment:// Was the fitting hardware supplied complete? If no what was not supplied	Yes	No	
Did the installation go well?	Yes	No	
Please provide comments			
Please draw diagrams if you need to.			

Post to Reply Paid 122 PO Box 122 Margate QLD 4019 **Fax to** (07) 3283 1168



East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

DESPATCH CHECKLIST NBHU70SY

	110100	7 1
Work Order #		
Finish:		
Transport:		
Due Date:		
 O 2 – Steel 1 O 1 – Bolt K 	mounting brackets. Kit.	See other side of this page for photos of all mounts
If NO	s product "the best it fix before continuing	can be" Yes / Checker initials
All parts <u>checked</u> aı	id <u>completed</u> by:	
Nut and bolts:		Date//
Order control:		Date//
Final wrap check:		Date//



Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

