



REPLACES: 03.06.16 REVISED: 30.03.21

NBT250SY / NB7T250SY

FITTING INSTRUCTIONS

TOYOTA LANDCRUISER 200 SERIES 01/16on 76mm NUDGE BAR and 76mm SERIES 2 NUDGE BAR VEHICLE FRONTAL PROTECTION SYSTEM (VFPS) FOR AIR BAG & ADR COMPLIANT VEHICLES

Ensure these instructions are left with the vehicle owner and/or operator.

Check installation hardware before commencing.

- 1. From underside of vehicle, remove tow hooks, four 17mm head bolts (2 per side). See figure 1.
- 2. Using a sharp knife, trim front from the plastic under body shields. See figure 2 and 3.
- 3. Using four M12 x 55 bolts, spring washers and flat washers (supplied), fit ECB Steel mounting brackets (supplied) to vehicle through original tow hook assembly back to original holes in chassis rail. **Securely tighten only**. **See figure 4.**
- 4. Align mounts to match inner measurements of protection bar.
- 5. Fit protection bar to mounts using two M10 X 40 bolts, flat washers, spring washers and nuts (supplied) in rear holes and two M10 x 40 bolts and washers on wire, flat washers, spring washers and nuts (supplied) in front holes.
- 6. Align ECB protection bar to vehicle. **See figures 5 and 6** for 76mm Nudge Bar and **figures 7 and 8** for 76mm Nudge Bar.
- 7. Tighten all bolts.

ENSURE NUMBER PLATE IS CLEARLY VISABLE

Note: When fitting/refitting the licence plate to the vehicle, ensure there is no obstruction to licence plate vision in accordance with local authorities. If required relocate licence plate to an alternate location.

Further VFPS Notes:

- a) Do not attach VFPS to the vehicle using anchorages not intended for this purpose (e.g. engine mounting bolts).
- b) Do not use this product for any vehicle make or model, other than those specified by the VFPS manufacturer.
- c) Do not remove the plaque or label from the VFPS.
- d) Do not modify the structure of the VFPS in any way.
- e) No accessory or fitment should project forward of the VFPS forward profile.
- f) ENSURE THESE INSTRUCTIONS ARE LEFT WITH VEHICLE OWNER AND/OR OPERATOR.

IMPORTANT INFORMATION

Periodically check bolts and nuts for correct tightness, especially if travelling on rough roads



FITTING KIT

1 – Pair ECB Steel mounting brackets	2 – M10 x 1.5 x 40 bolts
4 – M12 x 1.25 x 55mm bolts	6 – M10 flat washers
4 – M12 flat washers	4 – M10 spring washers
4 – M12 spring washers	4 – M10 x 1.5 nuts
$2 - M10 \times 1.5 \times 40$ bolts and washers on 300mm wire	



Figure 1: Genuine Tow hooks





Figure 3: Trimmed under body shields.



Figure 4: ECB Steel mounting brackets fitted







Figure 5: 76mm Nudge Bar front view shown



Figure 6: 76mm Nudge Bar side view shown



Figure 7: 76mm Series 2 Nudge Bar front view shown



Figure 8:76mm Series 2 Nudge Bar side view shown





Thank you for purchasing an ECB Product

Please ensure that you read the below and complete the warranty registration.



Vehicle Owner / Operator Responsibilities and Product Care

Important Information

It is the responsibility of the vehicle owner and operator to ensure all nuts and bolts are check periodically, especially when travelling on corrugated roads. Please ensure these are tighten as per the steps in the provided fitting instructions.

While ECB products are manufactured from high tensile alloy the vehicle owner / operator must check any steel mounting brackets or steel auxiliary parts for signs of corrosion. If you find any corrosion, please contact ECB Pty Ltd to discuss an appropriate solution – 1800 069 145 or www.ecb.com.au.

Product Care

Polished Products

Being a premium mirror polished finish, regular maintenance will be required to keep that iconic ECB shine. We recommend using our own brand of Aluminium Polish. This formula has been tried and tested and in our opinion is the world's best standard.

Directions: Apply a small quantity of Aluminium Polish to a clean soft cloth and rub the metal surface. The longer the rubbing the brighter the surface becomes. Wipe off Aluminium Polish with clean soft cloth. Also suitable for motorised buffing machines. Note: There are more specific details on the polish bottle. Please read before use.

Powder Coated Products

Our powder coated finishes are very low maintenance. In fact, there is actually very little you will ever need to do for this product. Just clean it as you would your car and it will stay looking good as new.

ECB Aluminium Polish

When you're looking for that showroom finish look for your polished automotive products, you can depend on the no compromise quality of East Coast Bullbars Aluminium Polish. This specifically designed product is the best polish available and we guarantee that this \$#!+ works. Within our decades of manufacturing polished alloy products, we have trialled a large range of different polishes on the market and believe without a doubt that nothing beats the finish quality of East Coast Bullbars Aluminium Polish.

East Coast Bullbars Aluminium Polish is excellent for use by hand and is ideal for polished bullbars, nudge bar and stainless-steel products. This polish will clean, polish and protect your product from the elements whilst bringing your products back to that showroom finish look.







Warranty Registration

Please Register your purchase online www.ecb.com.au/warranty-registration
If you have any questions, please contact our national office on 1800 069 145 or www.ecb.com.au

Or post the below information back to ECB, PO Box 122, Margate, QLD 4019.

Contact Details		
Name:		
Address:		
Email:		
Phone:		
Purchase Details		
Purchased from:		
Date of Purchase:		
Product Details		
(You can find this information on the silver label of your ECB Product)		
Part Number:		
Work Order Number:		

By submitting this registration, you automatically subscribe to ECB's mail outs. You can unsubscribe at any time.





We value your comments

Dear Fitter,

ECB would like to know how you went with the installation of this product. We value your comment and may need to contact you to clarify some details so please complete your contact details clearly.

We would appreciate if you could complete as many of the following details as possible.

Your Name:	Your contact No.	
Product Part No.	Product Invoice No.	
Product Description:	Make, model, and year of vehicle:	
Product Work Order No.	Company you're from/Company product purchased from:	
Date of Fitment:/ Was the fitting hardware supplied complete? If no what was not supplied	Yes No	
Did the installation go well?	Yes No	
Please provide comments		
Please draw diagrams if you need to.		

Post to Reply Paid 122 PO Box 122 Margate QLD 4019 Email to: info@ecb.com.au





DESPATCH CHECKLIST NBT250SY / NB7T250SY

Work Order #	See other side of
Finish:	this page for
Transport:	photos of all
Due Date:	mounts

- O 1– Steel mounting brackets.
- *O* 1 − Bolt Kit.



Is this product "the best it can be" Yes If NO fix before continuing

All parts checked and completed by:

Nut and bolts:	Date//
Order control:	Date//
Final wrap check:	Date//
	Wrapper's initials / Checker initial





