Tel: 07 3897 5700 Fax: 07 3283 1168 ecb@ecb.com.au www.ecb.com.au 29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

8T70SY / NBT70SY / NB6T70SY

REPLACES: 23.05.00 REVISED: 11.07.10

FITTING INSTRUCTIONS

PRADO 7/96-2/03 TYPE 8 PROTECTION BAR, 76mm NUDGE BAR & 63mm SERIES 2 NUDGE BAR VEHICLE FRONTAL PROTECTION SYSTEM (VFPS) FOR AIR BAG & ADR COMPLIANT VEHICLES

Check installation hardware before commencing.

1. Remove the tie-down hooks and towing hook form bottom of chassis.

NOTE: The towing hook is re-installed but the two tie-down hooks are discarded.

- 2. Feed the steel mount (supplied) out through the slot in the bumper and attach to the chassis using the original bolts. **HAND TIGHTEN ONLY**.
- 3. Attach ECB Protection Bar / Nudge Bar to the inside of steel mounts. Use 3/8 x 1 ½ bolts/nuts (supplied).
- 4. Level bullbar on vehicle.

NOTE: When viewed from the side the bar is designed so that the top of the mount is horizontal when correctly positioned. **See figure 1** for Type 8 alignment.

5. TIGHTEN ALL BOLTS.

ENSURE NUMBER PLATE IS CLEARLY VISABLE

Note: When fitting/refitting the licence plate to the vehicle, ensure there is no obstruction to licence plate vision in accordance with local authorities. If required relocate licence plate to an alternate location.

Further VFPS Notes:

- a) Do not attach VFPS to the vehicle using anchorages not intended for this purpose (e.g. engine mounting bolts).
- b) Do not use this product for any vehicle make or model, other than those specified by the VFPS manufacturer.
- c) Do not remove the plaque or label from the VFPS.
- d) Do not modify the structure of the VFPS in any way.
- e) No accessory or fitment should project forward of the VFPS forward profile.
- f) ENSURE THESE INSTRUCTIONS ARE LEFT WITH VEHICLE OWNER AND/OR OPERATOR.

IMPORTANT INFORMATION

Periodically check bolts and nuts for correct tightness, especially if travelling on rough roads

Tel: 07 3897 5700 Fax: 07 3283 1168 ecb@ecb.com.au www.ecb.com.au 29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

FITTING KIT

2 – Steel mounts.	
$4 - 3/8 \times 1^{-1/4}$ unc bolts.	
4 - 3/8 unc nuts	

8 - 3/8 flat washers.

4 - 3/8 spring washers.



Figure 1 – Type 8 Alignment



Tel: 07 3897 5700 Fax: 07 3283 1168 ecb@ecb.com.au www.ecb.com.au 29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

We value your comments

Dear Fitter,

ECB would like to know how you went with the installation of this product. We value your comment and may need to contact you to clarify some details so please complete your contact details clearly.

We would appreciate if you could complete as many of the following details as possible.

Your Name: Product Part No. Product Description:	Your contact No. Product Invoice No. Make, model, and year of vehicle: Company your from/Company product purchased from:		
			Product Work Order No.
			Was the fitting hardware supplied complete?
If no what was not supplied			
	Yes No		
Did the installation go well?			
Please provide comments			
Please draw diagrams if you need to			

Post to Reply Paid 122 PO Box 122 Margate QLD 4019 Fax to (07) 3283 1168



Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia

Po Box 122 Margate QLD 4019 Australia



Tel: 07 3897 5700 Fax: 07 3283 1168 ecb@ecb.com.au www.ecb.com.au 29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

DESPATCH CHECKLIST 8T70SY / NBT70SY / NB6T70SY

0		
Work Order #		
Finish:		
Transport:		
Due Date:		
 O 2 – Steel 1 O 1 – Bolt K 	mounting brackets. Kit.	See other side of this page for photos of all mounts
If NO	s product "the best it can fix before continuing	an be" Yes/
All parts checked as	na <u>completea</u> by:	
Nut and bolts:		Date//
Order control:		Date//



Tel: 07 3897 5700 Fax: 07 3283 1168 ecb@ecb.com.au www.ecb.com.au 29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019

Australia

