



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

BN45

REPLACES: 08.02.10

REVISED: 09.07.10

FITTING INSTRUCTIONS

GQ / MAVERICK COIL SPRING WAGON/SWB/UTE BIG TUBE™ BULLBAR VEHICLE FRONTAL PROTECTION SYSTEM (VFPS)

Check installation hardware before commencing.

1. Remove the bumper bar from vehicle.
2. Remove park light / indicators from the vehicle and splice ECB park light / indicator wiring (supplied – connected to indicator / park lights with plug) into original park light / indicator wiring. Use cable locks (supplied). Refit park light / indicators into vehicle.
4. Fit ECB indicator / park lights into protection bar as per instructions supplied with the LED indicator kit.
NOTE: Ensure park light is to outside. See figure 1.
5. Position the protection bar with alloy mountings going into the opening in the front of the chassis rails.
6. Attach ½ x 1½ bolt with wire (supplied) inside chassis rail through existing hole in chassis rail into slotted hole on lower horizontal alloy protection bar bracket.
7. Using original bumper holes on the chassis. Use 9/16 x 2 bolts with 40mm **round** alloy washer plates (supplied) in rear holes.
8. Slide the plate with nuts attached (supplied) through the opening in the front of the chassis rail to match the holes in the protection bar. **NOTE-** There are left and right sides for required clearance to chassis.
9. To the front holes on the chassis. Use 9/16 x 2 bolts with 50mm x 50mm alloy washer plates (supplied) to the outside of the chassis rail. Use alloy washer plates with off set holes.
10. Align ECB protection bar with vehicle and **TIGHTEN ALL BOLTS.**
11. Connect wiring into park light / indicators in the ECB protection bar. **CHECK FOR CORRECT OPERATION.**

ENSURE NUMBER PLATE IS CLEARLY VISABLE

Note: When fitting/refitting the licence plate to the vehicle, ensure there is no obstruction to licence plate vision in accordance with local authorities. If required relocate licence plate to an alternate location.



East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

WORLD'S BEST
ALLOY BULLBARS

Further VFPS Notes:

- a) Do not attach VFPS to the vehicle using anchorages not intended for this purpose (e.g. engine mounting bolts).
- b) Do not use this product for any vehicle make or model, other than those specified by the VFPS manufacturer.
- c) Do not remove the plaque or label from the VFPS.
- d) Do not modify the structure of the VFPS in any way.
- e) No accessory or fitment should project forward of the VFPS forward profile.
- f) **ENSURE THESE INSTRUCTIONS ARE LEFT WITH VEHICLE OWNER AND/OR OPERATOR.**

IMPORTANT INFORMATION

Periodically check bolts and nuts for correct tightness, especially if travelling on rough roads

FITTING KIT

4 – 9/16 x 2 bolts.
2 – 9/16 nut plates. NOTE left and right side plates required
2 – 40mm round alloy plates with 9/16 hole in centre.
2 – 50mm x 50mm x 6mm alloy plates with 9/16 off set hole.
4 – 9/16 flat washers.
4 – 9/16 spring washers.
2 – ½ x 1 ½ bolts on wire.
2 – ½ nuts.
2 – ½ spring washers.
1 – ECB LED Indicator / Park light kit
6 – Cable locks.




Figure 1
Stainless steel self-tappers



East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

WORLD'S BEST
ALLOY BULLBARS

We value your comments

Dear Fitter,

ECB would like to know how you went with the installation of this product. We value your comment and may need to contact you to clarify some details so please complete your contact details clearly.

We would appreciate if you could complete as many of the following details as possible.

Your Name:	Your contact No.
Product Part No.	Product Invoice No.
Product Description:	Make, model, and year of vehicle:
Product Work Order No.	Company your from/Company product purchased from:

Date of fitment: ____/____/____

Was the fitting hardware supplied complete?

Yes

No

If no what was not supplied

Did the installation go well?

Yes

No

Please provide comments

Please draw diagrams if you need to.

Post to
Reply Paid 122
PO Box 122
Margate QLD 4019

Fax to
(07) 3283 1168



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia



WORLD'S BEST
ALLOY BULLBARS

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

DESPATCH CHECKLIST BN45

Work Order #	
Finish:	
Transport:	
Due Date:	

- 1 – Bolt Kit
- 1 – ECB LED Indicator / Park light kit.
- 2 – ECB overrides – **Fitted to Bar**



Is this product “the best it can be” Yes _____ / _____
Wrapper's initials / Checker initials
 If NO fix before continuing

All parts checked and completed by:

Nut and bolts: _____ Date ___/___/___

Order control: _____ Date ___/___/___

Final wrap check: _____ Date ___/___/___