



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

NB6J50SY

REPLACES: 19.09.00

REVISED: 09.07.10

FITTING INSTRUCTIONS

JEEP GRAND CHEROKEE 8/99-6/05 63mm NUDGE BAR VEHICLE FRONTAL PROTECTION SYSTEM (VFPS) FOR AIR BAG & ADR COMPLIANT VEHICLES

Check installation hardware before commencing.

1. Remove bumper cover from vehicle. Remove 3 plastic clips (each side) for plastic inner guards, 1 self tap screw (each side) top side return on bumper cover, 3 plastic clips under lower bumper cover, 7 PK screws in grille (LTD Model) then slide bumper cover forward.
2. Remove drivers side tow bracket from chassis.
3. Enlarge 2 diagonally opposite square holes in chassis to accept 7/16 bolts.
4. Flatten lower lip on chassis where steel mounts are to be fitted.
5. Insert nut plates (supplied) into chassis. **NOTE:** Left and right.
6. Attach steel mounting bracket (supplied) to lower chassis. Insert bolts (supplied) into nut plate. Use 7/16 x 1 ½ bolts/washers. **NOTE:** Rear inward bolt is inserted from inside chassis downwards.
7. Align steel mounts centrally with vehicle taking note of measurement of protection bar bracket so that protection bar can slide in on inside of steel mounts.
8. **TIGHTEN** steel mount in position.
9. Re-attach bumper cover.
10. Attach ECB protection bar to inside of steel mounts. Use 3/8 x 1 ¼ bolt and nuts (supplied). Access rear holes via air intakes in bumper.
11. Align protection bar with vehicle. **NOTE:** That protection bar is designed to follow contour of vehicle when spot tabs are level protection bar is in desired position. **TIGHTEN ALL BOLTS**
12. **NOTE:** Towing points are provided on steel mounts. These are designed to be used together via a link for straight line towing and light snatching using an elastic type snatch rope. Always take care when towing or snatching and observe safety requirements of equipment being used.

ENSURE NUMBER PLATE IS CLEARLY VISABLE

Note: When fitting/refitting the licence plate to the vehicle, ensure there is no obstruction to licence plate vision in accordance with local authorities. If required relocate licence plate to an alternate location.



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

Further VFPS Notes:

- a) Do not attach VFPS to the vehicle using anchorages not intended for this purpose (e.g. engine mounting bolts).
- b) Do not use this product for any vehicle make or model, other than those specified by the VFPS manufacturer.
- c) Do not remove the plaque or label from the VFPS.
- d) Do not modify the structure of the VFPS in any way.
- e) No accessory or fitment should project forward of the VFPS forward profile.
- f) **ENSURE THESE INSTRUCTIONS ARE LEFT WITH VEHICLE OWNER AND/OR OPERATOR.**

IMPORTANT INFORMATION

Periodically check bolts and nuts for correct tightness, especially if travelling on rough roads

FITTING KIT

2 – Steel mounting brackets.	4 – 3/8 x 1 ¼ bolts/nuts.
2 – Steel nut plates.	4 – 3/8 flat washers.
8 – 7/16 x 1 ½ bolts only.	4 – 3/8 spring washers.
8 – 7/16 flat washers.	8 – 7/16 spring washers.



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia



WORLD'S BEST
ALLOY BULLBARS

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

DESPATCH CHECKLIST NB6J50SY

Work Order #	
Finish:	
Transport:	
Due Date:	

- 2 – Steel mounting brackets.
- 2 – Steel nut plates.
- 1 – Bolt Kit.

**See other side of
this page for
photos of all
mounts**



Is this product “the best it can be” Yes _____ / _____
Wrapper's initials / Checker initials
 If NO fix before continuing

All parts checked and completed by:

Nut and bolts: _____ Date ___/___/___

Order control: _____ Date ___/___/___

Final wrap check: _____ Date ___/___/___



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

