



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

NBI37SY

REPLACES: 00.00.00
REVISED: 22.10.12

FITTING INSTRUCTIONS

IVECO DAILY 2-12 on VAN AND CAB CHASSIS VEHICLE FRONTAL PROTECTION SYSTEM (VFPS) BAR FOR AIR BAG AND ADR COMPLIANT VEHICLES

Check installation hardware before commencing.

1. Remove front four bolts (two 10mm head bolts and two 8mm head bolts) from engine splash guard. Allow to hang.
2. On drivers side. Using M10 x 35 bolt, flat washer and spring washer, fit steel mount thru steel mount to underside of chassis rail, long leg to outside. **See figure 1. WARNING:** The use of a longer bolt could result in damage to the radiator mounted above. Install M10 x 40 bolts, flat washers, spring washers and nuts to front and rear holes. **FINGER TIGHTEN ONLY.**
3. Repeat for passenger's side.
4. Align mounts centrally to vehicle and at width to suit alloy protection bar. Inside - inside of bar to outside – outside of mounts. **TIGHTEN ALL BOLTS. See figure 2.** Refit 4 bolts previously removed from engine splash guard.
5. Lay protection bar on soft coverings (to not damage bar) in front of vehicle. **See figure 3.** Fit rear of bar to outside of mounts using M10 x 40 bolt and flat washer to rear hole(per side). Swing bar up onto mounts and fit M10 x 40 and flat washer on wire, flat washer, spring washer and nut to front hole of Protection bar. Turn rear bolt to inside and fit flat washer, spring washer and nut to bolt. **FINGER TIGHTEN ONLY.**
6. Align protection bar with vehicle as high up on mount as possible. **See figure 4 and 5** for 76mm Nudge Bar
7. **TIGHTEN ALL BOLTS.**

ENSURE NUMBER PLATE IS CLEARLY VISABLE

Note: When fitting/refitting the licence plate to the vehicle, ensure there is no obstruction to licence plate vision in accordance with local authorities. If required relocate licence plate to an alternate location.

Further VFPS Notes:

- a) Do not attach VFPS to the vehicle using anchorages not intended for this purpose (e.g. engine mounting bolts).
- b) Do not use this product for any vehicle make or model, other than those specified by the VFPS manufacturer.
- c) Do not remove the plaque or label from the VFPS.
- d) Do not modify the structure of the VFPS in any way.
- e) No accessory or fitment should project forward of the VFPS forward profile.
- f) **ENSURE THESE INSTRUCTIONS ARE LEFT WITH VEHICLE OWNER AND/OR OPERATOR.**

IMPORTANT INFORMATION

Periodically check bolts and nuts for correct tightness, especially if travelling on rough roads



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

FITTING KIT

1 – Pair ECB steel mounts.	10 – M10 x 1.25 nuts.
6 – M10 x 1.25 x 40 bolts.	18 – M10 flat washers.
2 – M10 x 1.25 x 35 bolts.	10 – M10 spring washers.
2 – M10 x 1.25 x 40 bolts, washers on 300mm wire.	



Figure 1: Passengers side shown. Use M10 x 35 bolt, flat washer and spring washer only



Figure 2: Mounts fitted to vehicle.



Figure 3: Protection bar fitment, on soft covering with rear bolts installed.



Figure 4: 76mm Nudge Bar side view



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia



Figure 5: 76mm Nudge bar, front view.



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

We value your comments

Dear Fitter,

ECB would like to know how you went with the installation of this product. We value your comment and may need to contact you to clarify some details so please complete your contact details clearly.

We would appreciate if you could complete as many of the following details as possible.

Your Name:	Your contact No.
Product Part No.	Product Invoice No.
Product Description:	Make, model, and year of vehicle:
Product Work Order No.	Company your from/Company product purchased from:

Date of fitment: ____/____/____

Was the fitting hardware supplied complete?

Yes

☐

No

☐

If no what was not supplied

Did the installation go well?

Yes

☐

No

☐

Please provide comments

Please draw diagrams if you need to.

Post to

Reply Paid 122

PO Box 122

Margate QLD 4019

Fax to

(07) 3283 1168



WORLD'S BEST
ALLOY BULLBARS

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

DESPATCH CHECKLIST NBI37SY

Work Order #		See other side of this page for photos of all mounts
Finish:		
Transport:		
Due Date:		

☐ 1 – Pair steel mounting brackets.

☐ 1 – Bolt Kit.



Is this product “the best it can be” Yes _____ / _____
If NO fix before continuing
Wrapper's initials / Checker initials

All parts checked and completed by:

Nut and bolts: _____ Date ____/____/____

Order control: _____ Date ____/____/____

Final wrap check: _____ Date ____/____/____



**WORLD'S BEST
ALLOY BULLBARS**

East Coast Bullbars (ECB Pty Ltd)

Tel: 07 3897 5700

Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St
Clontarf QLD 4019
Australia

Po Box 122
Margate QLD 4019
Australia

