Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

NBM57SY / NB6M57SY

REPLACES: 04.09.01 REVISED: 24.07.10

FITTING INSTRUCTIONS

TRITON MK MO2 76mm NUDGE BAR & 63mm SERIES 2 NUDGE BAR VEHICLE FRONTAL PROTECTION SYSTEM (VFPS) FOR AIR BAG & ADR COMPLIANT VEHICLES

Check installation hardware before commencing.

- 1. Remove lower 14mm head bolt from bumper/crash can bracket (each side).
- 2. Attach ECB steel mounting bracket on outside of chassis. **See figure 1 & 2**. Reinsert original bumper/crash can bracket bolt. **FINGER TIGHTEN ONLY**. Use 3/8 x 1 ½ bolts/nuts and washers (supplied) for rear hole.
- 3. Hold ECB steel mounting bracket as high as possible on chassis, level and **TIGHTEN ALL BOLTS**. **NOTE:** Ensure mounts are level with each other. **See figure 3.**
- 4. Attach ECB protection bar to outside of steel mounting brackets. Use 3/8 x 1 ½ bolt/nuts and washers for rear holes. For front holes feed 3/8 x 1 ½ bolts/washers on wire (supplied) inside tube and out through front holes. Use 3/8 nuts/washers (supplied).
- 5. Align ECB protection bar with vehicle, see figure 3 for Type 8 side view. TIGHTEN ALL BOLTS.

ENSURE NUMBER PLATE IS CLEARLY VISABLE

Note: When fitting/refitting the licence plate to the vehicle, ensure there is no obstruction to licence plate vision in accordance with local authorities. If required relocate licence plate to an alternate location.

Further VFPS Notes:

- a) Do not attach VFPS to the vehicle using anchorages not intended for this purpose (e.g. engine mounting bolts).
- b) Do not use this product for any vehicle make or model, other than those specified by the VFPS manufacturer.
- c) Do not remove the plaque or label from the VFPS.
- d) Do not modify the structure of the VFPS in any way.
- e) No accessory or fitment should project forward of the VFPS forward profile.
- f) ENSURE THESE INSTRUCTIONS ARE LEFT WITH VEHICLE OWNER AND/OR OPERATOR.

IMPORTANT INFORMATION

Periodically check bolts and nuts for correct tightness, especially if travelling on rough roads

FITTING KIT

2 – ECB Steel mounting brackets.	6 - 3/8 nuts.
$2 - 3/8 \times 1^{-1/4}$ bolts.	10 - 3/8 flat washers.
$2 - 3/8 \times 1 \frac{1}{2}$ bolts/washers on 200mm wire.	6 - 3/8 spring washers.
$2-3/8 \times 1 \frac{1}{2}$ bolts/nuts.	



Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia

Po Box 122 Margate QLD 4019 Australia



FIGURE 1 – Drivers side shown.



FIGURE 2 – Passenger side shown.



FIGURE 3



FIGURE 4



Tel: 07 3897 5700 Fax: 07 3283 1168 ecb@ecb.com.au www.ecb.com.au 29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

We value your comments

Dear Fitter,

ECB would like to know how you went with the installation of this product. We value your comment and may need to contact you to clarify some details so please complete your contact details clearly.

We would appreciate if you could complete as many of the following details as possible.

Your Name:	Your contact No.		
Product Part No.	Product Invoice No.		
Product Description:	Make, model, and year of vehicle:		
Product Work Order No.	Company your from/Company product purchased from:		
Was the fitting hardware supplied complete?	Yes No		
If no what was not supplied			
Did the installation go well?	Yes No		
Please provide comments			
Please draw diagrams if you need to.			

Post to Reply Paid 122 PO Box 122 Margate QLD 4019 **Fax to** (07) 3283 1168



Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia

Po Box 122 Margate QLD 4019 Australia



Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia Po Box 122 Margate QLD 4019 Australia

DESPATCH CHECKLIST NBM57SY / NB6M57SY

	Work Order #		
	Finish:		
	Transport:		
	Due Date:		
	 O 2 – ECB 3 O 1 – Bolt F 	Steel mounting brackets. Kit.	See other side of this page for photos of all mounts
		s product "the best it can be" I fix before continuing	Yes/
F	All parts <u>checked</u> ar	nd completed by:	
	Nut and bolts:		Date//
	Order control:		Date//

Final wrap check:

_Date__/__/__



Tel: 07 3897 5700 Fax: 07 3283 1168

ecb@ecb.com.au www.ecb.com.au

29 Snook St Clontarf QLD 4019 Australia

Po Box 122 Margate QLD 4019 Australia

